

# MC3190G



## Quick Start Guide




<http://www.motorola.com/mc3100>  
See User Guide for more information

### FEATURES


#### MC3190G




#### Comm/Charge Cables




#### Rubber Boot



#### Stylus Removal




### BATTERY REMOVAL/INSTALLATION




### CHARGING INSTRUCTIONS


LED Indicators: Slow Flash = Normal Charge | Solid Amber = Full Charge | Fast Flash = Charging Error



Four Slot Spare Battery Charger





Single Slot Serial Cradle



Four Slot Cradles  
Charge-Only Cradle and Ethernet Cradle

## HEADSET CONNECTION





### ALTERNATE LEFT AND RIGHT HANDS

**TAKING BREAKS AND TASK ROTATION RECOMMENDED**

## OPTIMUM UPRIGHT BODY POSTURES



## Avoid Extreme Wrist Angles



## OPTIMUM BODY POSTURE


### Optimum Body Posture for Low Scanning




Alternate left  
and right knees



AVOID BENDING



AVOID REACHING



Alternatete left  
and right hand

## Optimum Body Posture for High Scanning



Use a ladder

### Taking breaks and task rotation recommended

**Local Contact:** \_\_\_\_\_

**MOTOROLA**

Motorola, Inc.  
One Motorola Plaza Holtzville, New York 11742-1300, USA

MOTOROLA and the Stylized M Logo and Symbol and the Symbol logo are registered in the U.S. Patent and Trademark Office. All other product or service names are the property of their respective owners.

© Motorola, Inc. 2009

© Motorola, Inc. 2009

72-124276-02 Rev A September 2009



<http://www.motorola.com/mc3100>

# MC3190G

## Recommended Usage Guide